



Lodge Farm, Gidding Road, Sawtry, Huntingdon, Cambs. PE28 5UL
 Email: info@bugfish.co.uk Website: www.bugfish.co.uk


What Type of Fitting do I need on my Housing Unit


If the thread is on the inside of your tap you will need a MALE FITTING

If the thread is on the outside of your tap you will need a FEMALE FITTING

How do I measure my Housing Unit?

Carefully remove the housing unit from the tap, use calipers or a ruler to measure at the indicated points on the diagram below to determine the correct size.

 Male Housing Unit	Size	Measurement A	Measurement B
Male	M24	23.4 mm	22 mm
Male	M21	20.2 mm	19 mm
Male	M20	19.6 mm	18 mm
Male	M18	17.7 mm	16 mm

 Female Housing Unit	Size	Measurement A	Measurement B
Female	M22	22 mm	21.1 mm
Female	M20	19 mm	18.2 mm
Female	M19	19 mm	17.3 mm
Female	M16	16 mm	15.0 mm